



ECOTIMBER[®] FLOATING FLOOR PAD INSTALLATION INSTRUCTIONS

1. Be sure the subfloor surface is clean and dry.*
2. Fill any significant holes, gaps, cracks or low spots in the subfloor.
3. Roll EcoTimber Floating Floor Pad underlayment over the subfloor **with the vapor barrier film facing up**.
4. The perimeter edges of Eco Timber Floating Floor Pad need to be 1/2 to 3/4 inches away from the wall.
5. At seams, pad edges should to be butted together, but not overlapped. Connect the seams by peeling the plastic strip off the tape side of one roll and adhering it to the extended tab of the next roll.
6. Install flooring according to the manufacturer's installation instructions.

* Prior to installation of wood flooring over concrete, a calcium chloride moisture test is required. Vapor emission readings in excess of 3 lbs. per 1,000 square feet in 24 hours (or 2 lbs. if installing over radiant heat) may require additional protection such as a concrete sealant or polyethylene sheeting.